


GB



Caddy[®]

Arc 151i VRD

Arc 201i VRD



Instruction manual



DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007
The EMC Directive 2004/108/EC, entering into force 20 July 2007

Type of equipment

Welding power source

Type of designation etc.

Arc 151i VRD, Arc 201i VRD from serial number 828 xxx xxxx (2008 w.28)
Arc 151i VRD, Arc 201i VRD are members of the ESAB product family Caddy®

Brand name or trade mark

ESAB

Manufacturer or his authorised representatives established within the EEA:

Name, address, phone, website:

ESAB AB
Lindholmsallén 9
Box 8004, 402 77 GÖTEBORG, Sweden
Phone: +46 31 509 000, Website: www.esab.com

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1, Arc welding equipment – Part 1: Welding power sources
EN 60974-10, Arc welding equipment – Part 10: Electromagnetic compatibility (EMC) requirements

Additional information: Restrictive use, Class A equipment, intended for use in locations other than residential.

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within EEA, that the equipment in question complies with the safety requirements stated above.

Date

2012-07-31

Signature

A handwritten signature in black ink, appearing to read "Flavio Santos". The signature is stylized and somewhat cursive.

Flavio Santos
Clarification

Position

Global Director of Marketing
and Product Portfolio Equipment

1 SAFETY	4
2 INTRODUCTION	6
2.1 Equipment	6
3 TECHNICAL DATA	7
4 INSTALLATION	8
4.1 Location	8
4.2 Mains power supply	8
4.2.1 Recommended fuse sizes and minimum cable area	9
5 OPERATION	9
5.1 PFC - Power factor correction	9
5.2 Connections and control devices	9
5.3 Connection of welding and return cable	10
5.4 Overheating protection	10
5.5 MMA welding	10
5.6 TIG welding	11
5.7 Remote control unit	11
6 MAINTENANCE	11
6.1 Inspection and cleaning	12
7 FAULT-TRACING	12
7.1 Fault codes	12
8 ORDERING SPARE PARTS	13
9 DISMANTLING AND SCRAPPING	13
DIAGRAM	14
ORDER NUMBER	18
ACCESSORIES	19

1 SAFETY

Users of ESAB welding equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of welding equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the welding equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the welding equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding
2. The operator must ensure that:
 - no unauthorized person is stationed within the working area of the equipment when it is started up.
 - no-one is unprotected when the arc is struck
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts
4. Personal safety equipment
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves.
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
 - Make sure the return cable is connected securely.
 - Work on high voltage equipment **may only be carried out by a qualified electrician.**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand.



CAUTION

This product is solely intended for arc welding.



WARNING

Do not use the power source for thawing frozen pipes.



WARNING



Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.

ELECTRIC SHOCK - Can kill

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

ARC RAYS - Can injure eyes and burn skin.

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

NOISE - Excessive noise can damage hearing

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

MALFUNCTION - Call for expert assistance in the event of malfunction.


Read and understand the instruction manual before installing or operating.

PROTECT YOURSELF AND OTHERS!




CAUTION

Read and understand the instruction manual before installing or operating.



CAUTION

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.



ESAB can provide you with all necessary welding protection and accessories.

2 INTRODUCTION

Arc 151i, Arc 201i is a welding current power source intended for use with coated electrodes (MMA welding) and TIG welding.

ESAB's accessories for the product can be found on page 19.

2.1 Equipment

Arc 151i, Arc 201i is supplied with a 3 m welding cable, return cable, 3 m mains cable and an instruction manual for power source and control panel.

Control panel A33



Welding process parameters are controlled via the control panel.

NOTE! See the separate instruction manual for a detailed description of the control panel.

3 TECHNICAL DATA

	Arc 151i	Arc 201i
Mains voltage	230 V, 1 ~ 50/60 Hz	230 V, 1 ~ 50/60 Hz
Primary current		
I _{max} TIG	14 A	24 A
I _{max} MMA	22 A	25 A
Mains supply	Z _{max} 0.35 ohm	Z _{max} 0.31 ohm
No-load power	30 W	30 W
Setting range, MMA	4 A - 150 A	4 A - 170 A
Setting range, TIG	3 - 150 A	3 - 220 A
Permissible load at MMA		
25% duty cycle	150 A / 26.0 V	170 A / 26.8 V
60% duty cycle	100 A / 24.0 V	130 A / 25.2 V
100% duty cycle	90 A / 23.6 V	110 A / 24.4 V
Permissible load at TIG		
20% duty cycle	-	220 A / 18.8 V
25% duty cycle	150 A / 16.0 V	-
60% duty cycle	120 A / 14.8 V	150 A / 16.0 V
100% duty cycle	110 A / 14.4 V	140 A / 15.6 V
Power factor at maximum current		
MMA	0.99	0.99
TIG	0.98	0.99
Efficiency at maximum current		
MMA	80%	81%
TIG	77%	75%
Open-circuit voltage MMA/TIG with VRD	55 - 60 V < 35 V	55 - 60 V < 35 V
Operating temperature	-10° C - +40° C	-10° C - +40° C
Transportation temperature	-20° C - +55° C	-20° C - +55° C
Constant A-weighted sound pressure	< 70 dB	< 70 dB
Dimensions, l x b x h	418 x 188 x 208 mm	418 x 188 x 208 mm
Weight	8.1 kg	8.3 kg
Enclosure class	IP 23	IP 23
Application class	S	S

Mains supply, Z_{max}

Maximum permissible line impedance of the network in accordance with IEC 61000-3-11.

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40° C.

Enclosure class

The IP code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water. Equipment marked **IP23** is designed for indoor and outdoor use.

Application class

The symbol S indicates that the power source is designed for use in areas with increased electrical hazard.

4 INSTALLATION

The installation must be carried out by a professional.

Note

Mains supply requirements

High power equipment may, due to the primary current drawn from the mains supply, influence the power quality of the grid. Therefore connection restrictions or requirements regarding the maximum permissible mains impedance or the required minimum supply capacity at the interface point to the public grid may apply for some types of equipment (see technical data). In this case it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.


4.1 Location

Position the power source such that its cooling air inlets and outlets are not obstructed.

4.2 Mains power supply

Check that the welding power source is connected to the correct voltage and that the correct fuse size is used. A protective earth connection must be made in accordance with regulations

Location of rating plate



4.2.1 Recommended fuse sizes and minimum cable area

	Arc 151i	Arc 201i
Mains voltage	230 V \pm 10 %, 1-phase	230 V \pm 10 %, 1-phase
Mains frequency	50-60 Hz	50-60 Hz
Mains cable, area	3G2.5 mm ²	3G2.5 mm ²
Phase current I_{1eff}	11 A	14 A
Welding cable, area	16 mm ²	16 mm ²
Fuse		
anti-surge	16 A	16 A
type C MCB	13 A	16 A

NOTE!

The cable area and fuse rating above comply with Swedish regulations. Use the welding power source in accordance with the relevant national regulations.



5 OPERATION

5.1 PFC - Power factor correction

The Caddy™ Arc 151i/201i are 230 V single-phase power sources equipped with a PFC circuit making it possible to use the full range of the machine on a 16 A fuse. The PFC also protects the machines against fluctuating mains voltage and makes it safer to use with a generator. Caddy™ Arc 151i/201i can operate with extra long mains cables, over 100 m, giving you a very larger working radius.

5.2 Connections and control devices

- | | |
|---|--|
| <p>1 Connection (+)
MMA: for return cable or welding cable
TIG: for return cable</p> <p>2 Connection for remote control unit</p> <p>3 Control panel</p> | <p>4 Connection (+)
MMA: for return cable or welding cable
TIG: for Tig torch I</p> <p>5 Toggle switch for mains power supply 0 / 1</p> <p>6 Mains cable</p> |
|---|--|



5.3 Connection of welding and return cable

The power source has two outputs, a positive terminal (+) and a negative terminal (-), for connecting welding and return cables. The output to which the welding cable is connected depends on the type of electrode used. The connecting polarity is stated on the electrode packaging. Connect the welding cable to the terminal stated on the electrode packaging.

Connect the return cable to the other output on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact between the work piece and the output for the return cable on the power source.

5.4 Overheating protection

The welding power source has a thermal overload trip which operates if the temperature becomes too high, interrupting the welding current and lighting a yellow indicating lamp on the front of the power source. The thermal overload trip resets automatically when the temperature has fallen.

5.5 MMA welding

Arc 151i / 201i gives direct current, and you can weld most metals to alloy and non-alloy steel, stainless steel and cast iron.


Arc 151i / 201i allows you to weld most coated electrodes from Ø 1.6 to Ø 3.25.

MMA welding may also be referred to as welding with coated electrodes. Striking the arc melts the electrode, and its coating forms protective slag.

If, when striking the arc, the tip of the electrode is pressed against the metal, it immediately melts and sticks to the metal, rendering continued welding impossible.


Therefore, the arc has to be struck in the same way that you would light a match.

Quickly strike the electrode against the metal, then raise it so as to give an appropriate arc length (approx. 2 mm). If the arc is too long, it will crackle and spit before finally going out completely.



If you are working on a welding bench, check before attempting to strike the arc that residual waste metal, pieces of electrode or other objects on the bench do not insulate the part to be welded.

Once the arc has been struck, move the electrode from left to right. The electrode must be at an angle of 60° to the metal in relation to the direction of welding.



When you want to weld wide beads, or when you want the weld to be so thick that you have to weld in a number of layers, however, you have to use lateral movements.

5.6 TIG welding

TIG welding melts the metal of the workpiece, using an arc struck from a tungsten electrode, which does not itself melt. The weld pool and the electrode are protected by shielding gas.


TIG welding is particularly useful where high quality is demanded and for welding thin plate. Arc 151i / 201i also has good characteristics for TIG welding.

In order to TIG weld Arc 151i / 201i must be equipped with:

- a TIG torch with gas valve
- a welding gas cylinder (a suitable welding gas)
- a welding gas regulator (suitable gas regulator)
- tungsten electrode
- suitable auxiliary material, if necessary.

”Live TIG-start” (only A33 control panel)

With “Live TIG start” the arc strikes when the tungsten electrode is brought into contact with the workpiece and then lifted away from it.



5.7 Remote control unit

The remote control unit is connected to the remote control socket on the power source.

6 MAINTENANCE

Regular maintenance is important for safe, reliable operation.

Only those persons who have appropriate electrical knowledge (authorized personnel) may remove the safety plates to connect or carry out service, maintenance or repair work on welding equipment.



CAUTION

All guarantee undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the guarantee period.

6.1 Inspection and cleaning

Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on: the welding process, arc times, placement, and the surrounding environment. It is normally sufficient to blow down the power source with dry compressed air (reduced pressure) once a year.

Clogged or blocked air inlets and outlets otherwise result in overheating.

TIG torch

The TIG torch's wear parts should be cleaned and replaced at regular intervals in order to achieve trouble-free welding.

7 FAULT-TRACING

Try these recommended checks and inspections before sending for an authorized service technician.

Type of fault	Corrective action
No arc.	<ul style="list-style-type: none"> • Check that the mains power supply switch is turned on. • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check to see whether the MCB has tripped.
The welding current is interrupted during welding.	<ul style="list-style-type: none"> • Check whether the thermal cut-outs have tripped (indicated by the orange lamp on the front panel). • Check the mains power supply fuses.
The thermal cut-out trips frequently.	<ul style="list-style-type: none"> • Check to see whether the dust filter is clogged. • Make sure that you are not exceeding the rated data for the power source (i.e. that the unit is not being overloaded).
Poor welding performance.	<ul style="list-style-type: none"> • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct electrodes are being used. • Check the gas flow.

7.1 Fault codes

Arc 151i, 201i comes with built-in fault monitoring. If a fault occurs, a code is shown in the display. See instruction manual for the control panel.

8 ORDERING SPARE PARTS


Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.

Arc 151i, Arc 201i is designed and tested in accordance with the international and European standards EN 60974-1 and EN 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.

9 DISMANTLING AND SCRAPPING

Welding equipment primarily consists of steel, plastic and non-ferrous metals, and must be handled according to local environmental regulations.
Coolant must also be handled according to local environmental regulations.



Dispose of electronic equipment at the recycling facility!


In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.


As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.


Diagram


Arc 151i






Arc 201i





Arc 151i Arc 201i

Order number









Ordering no.	Denomination	Type
0460 445 873	Welding Power source	Caddy® Arc 151i, A33 Australian version
0460 445 874	Welding Power source	Caddy® Arc 201i, A33 Australian version
0460 449 074	Instruction manual Control panel	Caddy® A32, A33, A33
0459 839 028	Spare parts list	Caddy® Arc 151i, Arc 201i, A33

Instruction manuals and the spare parts list are available on the Internet at www.esab.com

Arc 151i Arc 201i

Accessories

	<p>Strap 0460 265 001</p>
	<p>Cable holder 2 pcs 0460 265 002</p>
	<p>Shoulder strap 0460 265 003</p>
	<p>Trolley for 5-10 litre gasbottle 0459 366 885</p>
	<p>Welding cable kit, Arc 151i 0700 006 898 Return cable kit, Arc 151i 0700 006 899 Welding cable kit, Arc 201i 0700 006 900 Return cable kit, Arc 201i 0700 006 901</p>
	<p>Tig torch TXH 150V, Arc 151i 0460 011 843 Tig torch TXH 200V, Arc 201i 0460 012 841</p>

Arc 151i Arc 201i

	<p>Remote control MMA 1 (10 m cable) 0349 501 024 MMA and TIG: current</p>
	<p>Foot control FS002 0349 090 886 MMA and TIG current</p>
	<p>Remote control unit AT1 0459 491 896 MMA and TIG: current</p>
	<p>Remote control unit AT1 CF 0459 491 897 MMA and TIG: rough and fine setting of current.</p>
	<p>Remote cable 12 pole - 8 pole</p> <p>5 m 0459 552 880 10 m 0459 552 881 15 m 0459 552 882 25 m 0459 552 883</p>

NOTES

A series of horizontal dotted lines for writing notes.

NOTES

Lined writing area consisting of 32 horizontal dotted lines.

ESAB subsidiaries and representative offices

Europe

AUSTRIA

ESAB Ges.m.b.H
Vienna-Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM

S.A. ESAB N.V.
Brussels
Tel: +32 2 745 11 00
Fax: +32 2 745 11 28

BULGARIA

ESAB Kft Representative Office
Sofia
Tel/Fax: +359 2 974 42 88

THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.
Vamberk
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK

Aktieselskabet ESAB
Herlev
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND

ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

FRANCE

ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY

ESAB GmbH
Solingen
Tel: +49 212 298 0
Fax: +49 212 298 218

GREAT BRITAIN

ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03

ESAB Automation Ltd

Andover
Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

HUNGARY

ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY

ESAB Saldatura S.p.A.
Bareggio (Mi)
Tel: +39 02 97 96 8.1
Fax: +39 02 97 96 87 01

THE NETHERLANDS

ESAB Nederland B.V.
Amersfoort
Tel: +31 33 422 35 55
Fax: +31 33 422 35 44

NORWAY

AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND

ESAB Sp.zo.o.
Katowice
Tel: +48 32 351 11 00
Fax: +48 32 351 11 20

PORTUGAL

ESAB Lda
Lisbon
Tel: +351 8 310 960
Fax: +351 1 859 1277

ROMANIA

ESAB Romania Trading SRL
Bucharest
Tel: +40 316 900 600
Fax: +40 316 900 601

RUSSIA

LLC ESAB
Moscow
Tel: +7 (495) 663 20 08
Fax: +7 (495) 663 20 09

SLOVAKIA

ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN

ESAB Ibérica S.A.
Alcalá de Henares (MADRID)
Tel: +34 91 878 3600
Fax: +34 91 802 3461

SWEDEN

ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB international AB

Gothenburg
Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND

ESAB AG
Dietikon
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

UKRAINE

ESAB Ukraine LLC
Kiev
Tel: +38 (044) 501 23 24
Fax: +38 (044) 575 21 88

North and South America

ARGENTINA

CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL

ESAB S.A.
Contagem-MG
Tel: +55 31 2191 4333
Fax: +55 31 2191 4440

CANADA

ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 02 20
Fax: +1 905 670 48 79

MEXICO

ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA

ESAB Welding & Cutting Products
Florence, SC
Tel: +1 843 669 44 11
Fax: +1 843 664 57 48

Asia/Pacific

AUSTRALIA

ESAB South Pacific
Archerfield BC QLD 4108
Tel: +61 1300 372 228
Fax: +61 7 3711 2328

CHINA

Shanghai ESAB A/P
Shanghai
Tel: +86 21 2326 3000
Fax: +86 21 6566 6622

INDIA

ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA

P.T. ESABindo Pratama
Jakarta
Tel: +62 21 460 0188
Fax: +62 21 461 2929

JAPAN

ESAB Japan
Tokyo
Tel: +81 45 670 7073
Fax: +81 45 670 7001

MALAYSIA

ESAB (Malaysia) Snd Bhd
USJ
Tel: +603 8023 7835
Fax: +603 8023 0225

SINGAPORE

ESAB Asia/Pacific Pte Ltd
Singapore
Tel: +65 6861 43 22
Fax: +65 6861 31 95

SOUTH KOREA

ESAB SeAH Corporation
Kyungnam
Tel: +82 55 269 8170
Fax: +82 55 289 8864

UNITED ARAB EMIRATES

ESAB Middle East FZE
Dubai
Tel: +971 4 887 21 11
Fax: +971 4 887 22 63

Africa

EGYPT

ESAB Egypt
Dokki-Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

SOUTH AFRICA

ESAB Africa Welding & Cutting Ltd
Durbanvill 7570 - Cape Town
Tel: +27 (0)21 975 8924

Distributors

For addresses and phone numbers to our distributors in other countries, please visit our home page

www.esab.com



www.esab.com

